



# SPRAY NOZZLES FOR INDUSTRIAL APPLICATIONS



## SPRAY NOZZLES & ASSEMBLY FITTINGS

GENERAL CATALOGUE

## PNR ITALIA



PNR Italy, founded in 1968, has always dedicated itself to the design and manufacturing of industrial spray nozzles and systems. In all these years PNR made major investments both in machinery and human resources to develop top quality products and today is one of the most modern spray nozzles manufacturing facilities in the world. We manufacture thousands of different products to offer our customers one of the most complete product ranges in the world, and keep focused on research plus innovation. Our machine tool park includes all high quality and latest model CNC machines, many of these built to our requirements to accomplish special manufacturing jobs. All products and their performance are strictly controlled and our Quality control system is certified by DNV according to ISO 9001 norms. Our nozzles design requires expertise in hydrodynamics and fluids handling technology as well as a deep manufacturing know-how to give the best performances. It's not just a matter of mechanical processing.

Nozzles play an important role in industry and only the use of reliable quality products prevent the risk of damage and serious losses in production processes. PNR has extended its sales network to 55 Countries all over the world in 2015. Our sales engineers, fully trained in all industrial applications of our products and with a high technical knowledge, can help customers in finding the best solution for their needs, from process planning to production facilities improvement. We do not supply products only but also provide integrated services and technical assistance.

## DISCLAIMER

Our products are manufactured with the best care and according to the latest developments of the technology available. However we cannot assure that every one of our products is perfectly fit for every specific application. The information in this catalogue is provided "as seen" and so we offer no warranty of any kind with respect to the subject matter or accuracy of the information contained herein. This publication may include technical inaccuracies or typographical errors and changes may be periodically made to the information herein without prior notice. As a result of continuous product improvement our documentation is regularly updated: please visit our website [www.pnr.eu](http://www.pnr.eu) to be always updated.

## PRODUCT WARRANTY

PNR products will be replaced or repaired at the option of PNR and free of charges if found defective in manufacturing, labelling and packaging. The above conditions will apply if notice of defects is received by PNR within 30 days from date of product installations or one year from date of shipment. The cost of above said replacement or repair shall be the exclusive remedy for any breach of any warranty, and PNR shall not be held liable for any damage due to personal injuries or commercial losses coming from product malfunction.

It is self-understood that no warranty may apply in case our products have been operated under nonacceptable conditions, like for example (but not limited to):

- Operation at pressures exceeding those shown in catalogue performance table
- Operation with or exposure to liquids containing abrasive particles
- Operation with or exposure to liquids producing a chemical attack on the nozzle material
- Mechanical damages to nozzle orifices, nozzle spray edge or body due to careless handling or assembling.

In all above cases, the customer must accept a nozzle life reduction below life expected, or performance parameters below the values in the catalogue.

The guarantee may be exercised as follows:

- By sending a precautionary report to PNR on the detected damages. This report can also be sent by email to this address: [quality@pnr.it](mailto:quality@pnr.it)
- If PNR ascertains that the manufacturing faults are actually subject to the warranty, the product shall have to be returned to the manufacturer in its original packaging prior request of authorization to the manufacturer and receipt of manufacturer's written authorization.
- The rejected goods shall have to be returned by the means that PNR will communicate to the customer and the transportation costs of returned merchandise will be entirely borne by the manufacturer.

## COPYRIGHT

All the contents (texts, images, graphics, layouts, etc.) of this document are property of PNR Italia Srl. Any redistribution or reproduction of part or all of the contents in any form is prohibited.

Our Quality System is  
certified ISO 9001:2015  
**COMPANY WITH  
QUALITY SYSTEM  
CERTIFIED BY DNV GL**  
**= ISO 9001:2015 =**




As any other industrial product, spray nozzles need to be precisely identified by means of a code in order to avoid mistakes.

PNR coding system was created bearing in mind the following requirements:

- Codes must be easily processed by a computer, in ascending order.
- Codes must be self-explaining with no need of additional descriptions.
- Codes must give the basic nozzle specifications so to be easily found in the catalogue.

Therefore, we have created our coding system as described here below:



## Capacity rank

Nozzles nominal flow rate, measured at 3.0 bar are highlighted on a yellow background in the catalogue tables. Flow values were calculated at different pressures.

Rank	Flow digits	Actual flow (l/min)
0	0 490	0.49
1	1 490	4.90
2	2 490	49.0
3	3 490	490
4	4 490	4900

## Some spray angle codes (degrees)

These codes serve as an indication only. Based on different types of nozzles, their significance can be occasionally different.

Code	Spray angle	Code	Spray angle	Code	Spray angle
A	0°	L	40°	T	80°
B	15°	M	45°	U	90°
C	20°	N	50°	J	110°
D	25°	Q	60°	W	120°
F	30°	R	65°	Y	130°
H	35°	S	75°	Z	180°

## Nozzle material codes

<b>A1</b>	Carbon steel	<b>D6</b>	Glassfibre reinforced PP	<b>G1</b>	Cast iron
<b>A2</b>	High speed steel	<b>D7</b>	High density polyethylene	<b>H1</b>	Titanium
<b>A8</b>	Zinc coated steel	<b>D8</b>	Polyvinylidene fluoride (PVDF)	<b>L1</b>	Monel 400
<b>A9</b>	Nickel coated steel	<b>D82</b>	PVDF, Injection molded	<b>L2</b>	Incolloy 825
<b>B1</b>	AISI 303 Stainless steel	<b>E0</b>	EPDM	<b>L8</b>	Hastelloy C276
<b>B2</b>	AISI 304 Stainless steel	<b>E1</b>	Polytetrafluorethylene (PTFE)	<b>P6</b>	Acr. But. Styrene (ABS)
<b>B21</b>	AISI 304L Stainless steel	<b>E2</b>	PTFE (15% glassfibers)	<b>P8</b>	EPDM 40 Shore
<b>B3</b>	AISI 316 Stainless steel	<b>E31</b>	Acetalic resin (POM)	<b>T1</b>	Brass
<b>B31</b>	AISI 316L Stainless steel	<b>E6</b>	LUCITE ® (PMMA)	<b>T2</b>	Brass, chrome plated
<b>C2</b>	AISI 416 Stainless steel, hardened	<b>E7</b>	Viton	<b>T3</b>	Copper
<b>D1</b>	Polyvinylchloride (PVC)	<b>E8</b>	Synthetic rubber (NBR)	<b>T5</b>	Bronze
<b>D2</b>	Polypropylene (PP)	<b>F5</b>	Ceramic	<b>T8</b>	Brass, nickel plated
<b>D3</b>	Polyamide (PA)	<b>F30</b>	Ruby insert, 303 body	<b>T81</b>	Brass, electroless nickel plated
<b>D4</b>	Nylon, Glassfibers reinforced	<b>F31</b>	Ruby insert, 316 body	<b>V1</b>	Aluminum
<b>D5</b>	Talcum filled Polypropylene	<b>F32</b>	Diamond insert, 303 body	<b>V7</b>	Aluminum, electroless n. plated
		<b>F33</b>	Diamond insert, 316 body		


## THE PROCESS OF ATOMIZATION

A liquid spraying process can be described as consisting of two phases, namely:

1. breaking of the liquid into separate droplets
2. directing the liquid drops onto a surface or an object, to achieve the desired result.


Modern technology allows for a strict control of different parameters of a liquid spray; for example precise information can be obtained about droplet size spectrum, droplets speed and liquid distribution onto the spray target. In recent years we've supported our customers in improving their productivity and market share by providing them cutting edge industrial techniques.

PNR is your best partner to help you enhance your productivity and quality.




## APPLICATIONS


Spraying a liquid through a spray nozzle can serve different purposes, among which the most important are the following:




**Cooling:** heat transfer by spraying liquids onto the products surface for a rapid cooling, such as continuous casting cooling in steelworks.




**Humidification:** spray of very little quantities of liquid onto the products surface into special chambers or rooms to raise relative humidity. A typical application is textiles humidification.




**Coating:** application of coatings or liquids on the food products surface. For example: oil-spraying on bread.



**Food processing:** spray to add specific ingredients or substances to speed up chemical reactions. For ex.: addition of fructose in fruit juices, etc.



**Washing:** remove dirt from the product surface spraying liquids at high pressure, like in vehicles pre-wash treatment.



**Pollution control:** use of atomized scrubbing liquids to capture particulate matter and/or gaseous pollutants in liquid droplets, like in web scrubbers and spray towers.

### How to choose the most suitable nozzle among those listed?

This is the first question most customers ask themselves. Do not be afraid to choose the wrong one. Contact us, tell us what you need and we will help you to make the right choice explaining how our nozzles work in a simple and user-friendly way.



## SPRAY NOZZLES TECHNICAL FEATURES

Several technical features must be taken into account to select the proper nozzle. This will be dealt with on the following page.

### 1. NOZZLE EFFICIENCY


A spray nozzle is a device that turns the pressure energy of a liquid flow into kinetic energy. The nozzle efficiency can be defined as the ratio between the energy available at the nozzle inlet and the energy which is actually used to increase the liquid speed and create the spray, the difference being the energy lost during the process because of friction. Depending on the nozzle type and for a good quality machining, the nozzle efficiency varies between 55% and 95% for the types that are commonly used in industrial processes. What above stated is not valid for air-assisted atomizers which require a much higher energy because of the losses inherent in the energy transfer from compressed air to liquid surface.

### 2. DROPLETS SIZE

The droplets size depends on the structure of the atomizer, intensity of the liquids energy, liquid surface tension and density. The size of the atomized droplets is not uniform. Therefore, the average droplets size becomes an important factor. For example, the droplets size in gas quenching towers is extremely important. If their size is too big, they do not fully evaporate leading to dust bag failure. On the contrary, if the droplets size is too small, it's not possible to lower the temperature to the desired level and high temperature may cause the dust bags burn out.

There are four ways to express the droplets size:

The Sauter Mean Diameter (SMD) is the most commonly used. It refers to the drop volume/surface area ratio and it's often shown as  $D_{32}$ ,  $\mu\text{m}$ (Micron) unit. ( $1\mu\text{m}=10^{-3}\text{mm}$ )



#### 1 ARITHMETIC MEAN DIAMETER

This is a diameter value which, multiplied by the local number of droplets in the sample, equals the addition of all droplets diameters.

#### 2 SURFACE MEAN DIAMETER

This is a diameter of such a droplet whose surface, multiplied by the total droplets number, equals the sum of all droplets surfaces.

#### 3 VOLUME MEAN DIAMETER

This is the diameter of such a droplet whose volume, multiplied by the total droplets number, equals the sum of all droplets volumes.

#### 4 SAUTER MEAN DIAMETER ( $D_{32}$ )

This is the diameter of such a droplet whose volume/area ratio, equals the ratio between the sum of all droplet volumes divided by the sum of all droplet surfaces.

### MEASUREMENT METHODS

SMD is tested using pure water at 30°C

#### Method by immersion

A glass dish containing 60% of silicone oil is passed quickly under the spraying nozzle. Silicon oil is heavier so the water droplets float on the oil surface. Every droplet diameter is recorded and the resulting average is the SMD. This is a difficult method to perform and for this reason it's rarely used.


#### Laser interferometer test

As different droplets have different PI, they produce different refraction angles. Therefore laser light can be used to measure their size. This type of method is fast and precise. PNR can perform this test with technologically advanced equipments and provide complete documentation containing test reports. Please contact us for more information.

SPRAY NOZZLES TECHNICAL FEATURES

3. SPRAY ANGLE

A spray angle is the angle formed by the cone of liquid leaving a nozzle orifice.  
 The spray angle and the distance between the nozzle orifice and the target surface to be covered determine the spray coverage. (See page 116)



4. IMPACT FORCE

The impact force is the force generated by the jet of water deflected by the impact surface and its strength can be expressed as a force in kg or pounds or as a pressure in a given point in  $\text{kg/mm}^2$  or  $\text{lb/inch}^2$ . The uniformity of a jet impact force and distribution influence the washing effect. Under the same operating conditions (same pressure and capacity), different types of nozzles can be used to perform an impact force test and the results are shown here below.



Straight nozzles > Flat fan nozzles > Hollow cone nozzles > Full cone and square nozzles

5. DISTRIBUTION

Engineers design nozzles with different spray distribution patterns. Patterns can be solid stream, full cone, hollow cone, flat spray, spoon flat fan. The nozzle design aims at the uniformity and impact force of the jet sprayed whether nozzles are used individually or overlapping. Below figures show detailed information for a variety of capacities and spray sections. We mark distribution on every page for your convenience.


This section provides a detailed breakdown of spray distributions. It consists of six columns, each representing a different nozzle type. Each column includes a top view of the spray cone, a middle view showing the spray as a series of vertical bars of varying heights, and a bottom view showing the spray pattern within a dashed square boundary. The patterns are: a diagonal line for flat fan convex, a diagonal bar for flat fan even, a solid circle for full cone convex, a solid circle for full cone even, a ring for hollow cone concave, and a single point for straight single-point.

<b>Flat fan</b> convex distribution	<b>Flat fan</b> even distribution	<b>Full cone</b> convex distribution	<b>Full cone</b> even distribution	<b>Hollow cone</b> concave distribution	<b>Straight</b> single-point distribution
--	--------------------------------------	---	---------------------------------------	--	--


## SPRAY NOZZLE

Although nozzles are used to atomize liquids, the atomization precision and effect are deeply influenced by their quality. With our expertise we fully understand our customers needs and expectations and our engineers set high quality control standards not only for the operating precision of our nozzles but also for product inspection. **PNR ensures the best atomizing effects and provides capacity and spray angle accuracy with a tolerance of  $\pm 10\%$  guarantee.** Below highlights of quality inspection.

1. Check if liquid flow and pressure are in direct proportion.
2. Check if spray angle is as required.
3. Check if capacity is as required.
4. Check if distribution is uniform.
5. Check if droplets diameter is uniform.




Check if liquid flow and pressure are in direct proportion.




Check if spray angle is as required.



Check if capacity is as required.




Check if distribution is uniform.



Check if droplets diameter is uniform.

## TECHNIQUES FOR SPRAY PRODUCTION

Many different hydrodynamics techniques can be used to produce a spray and most of them are used today for nozzles to be applied in industrial processes.




This is the simplest type of nozzle where an orifice is opened into a chamber where the liquid to be sprayed is fed under pressure. A spray is produced through the orifice with spray pattern, flow rate and spray angle depending upon the orifice edge profile and the design of the inside pressure chamber. Typical pressure nozzles are J series straight nozzles and F series high pressure flat fan nozzles.

Turbulence nozzles use specially shaped vanes which force the pressurized liquid into a whirl chamber producing its high-speed rotation. This breaks up the liquid which exists the nozzle orifice atomized at high-speed. Different nozzle structures and flow rates produce hollow cone, full cone and full square cone spray patterns. Typical turbulence nozzles are RA series hollow cone and D series full cone nozzles.



TECHNIQUES FOR SPRAY PRODUCTION

IMPACT NOZZLES



Here the desired spray shape is obtained producing an impact of the liquid jet onto a properly designed surface. The liquid jet is subsequently changed into a fluid lamina and then broken into drops with the desired spray pattern after leaving the nozzle edge. Typical impact nozzles are K series flat fan nozzles, E series spiral full cone nozzles and RC series hollow cone nozzles.




AIR ASSISTED ATOMIZERS




Air-assisted atomizers use their special design and pressurized gas to atomize a liquid and break it into tiny droplets (the smallest average particle size: 10 micron). Please refer to catalogue CTG AZ and contact us.

**Air-assisted nozzles** - Depending on the liquid supply, these nozzles are of two types: Pressure nozzles and Siphon nozzles.

PRESSURE NOZZLES



SIPHON NOZZLES



ULTRASONIC ATOMIZERS



**Ultrasonic atomizers** are sister products of air-assisted atomizers. The front-end has a titanium ultrasonic generator. It uses the energy of the high-speed impact to produce a high-frequency oscillation that micro-atomizes the liquid droplets. The special design produces tiny and uniform droplets (the average smallest particle size: 7 Micron). The advantages are vital to many applications. Ultrasonic atomizers have two phases of atomization. Phase one: liquids mix with pressurized air and produce tiny droplets to spray. Phase two: when the atomized droplets hit the ultrasonic generator they get micro-atomized generating smaller droplets. Please contact us for catalogue CTG AZ and more information.





## FULL CONE PATTERN

The shape of the tip determines the spray range of full cone nozzles. A typical application of these nozzles is continuous casting cooling when it's necessary to spray the same volume of liquids onto a surface to cool objects.

Our engineers design a series of full cone nozzles to satisfy different needs.

No matter what kind of full cone nozzles they are, they have unique applications.



### STANDARD FULL CONE (Turbulence nozzle)

These nozzles use a specially shaped vane placed at the nozzle inlet to give a rotational speed to the fluid flowing through the nozzle.

Because of the rotational speed of the fluid, water exiting the nozzle orifice is subjected to centrifugal force and opens up in the shape of a full cone.

The extent of the angle of the cone is a function of both exit speed (created from the inlet pressure) and the internal design of the nozzle. It can vary in practice from 15° to 120°.

These nozzles can be also produced as square full cone nozzles where the square shape of the pyramidal spray is obtained by a special design of the outlet orifice.

Two important details have to be noted from the system designer when using these type of nozzles:

1. The spray angle is measured on the side of the square section.
2. The square section of the spray rotates within the distance from the nozzle orifice to the target area.



### SPIRAL FULL CONE (Impact nozzle)

This is not properly a full cone but rather a continuous liquid curtain evolving with the shape of a spiral inside a conical volume. The disadvantage of a scarcely even distribution is compensated by an exceptionally good resistance to clogging, large orifice and vaneless which make this nozzle the best choice in those applications such as wet scrubber, fire-fighting systems, etc.



### MULTIPLE FULL CONE (Turbulence nozzle)

Several nozzles are grouped in a cluster with different spray directions. These nozzles produce large capacity of watermist.

If you need both large capacity and mist, multi-orifice full cone nozzles are the best option.

## FLAT FAN SPRAY PATTERN

A flat fan spray nozzle serves the purpose of spraying onto a surface or an object moving in a transverse direction with respect to the one of the jet surface, a typical example being the nozzles in a car washing tunnel. The vast majority of flat spray nozzles used in the industry work according to one of the following principles.

### IN LINE FLAT FAN (Pressure nozzle)

This is the general purpose flat fan nozzle where the liquid enters the nozzle in line with the axis length and is fed to a pressure chamber from where it is ejected through the nozzle orifice. Flow value and spray angle are determined respectively from the orifice cross section and the orifice edge profile.

### IN LINE STRAIGHT JET (Pressure nozzle)

Straight nozzles can be considered as flat fan nozzles as the only difference is the spray angle which is zero degrees in straight nozzles. These nozzles are often used in high-pressure operating environments where the wear resistance of the nozzles is very important. It ensures optimum service life and spray orientation. PNR offers a wide range of material selection.

- 416 hardened stainless steel
- Ruby nozzle + stainless steel body
- Tungsten carbide nozzle tip + stainless steel body

### SPOON FLAT FAN (Impact nozzle)

These nozzles feature a flat fan spray. According to the different arc design, these spoon flat fan nozzles can be of two types: high impact with narrow spray angle or low pressure with wide spray angle.

- Under the same operating conditions, narrow angle high impact nozzles produce a higher impact force than standard flat fan nozzles. They are suitable for cleaning environments that need strong impact force.
- Low pressure nozzles with wider spray angle produce a 130° spray angle and a large area of water curtain effect. Low-impact spray nozzles are widely used in various applications such as foam removal, water curtain for gas separation, fruits and vegetables cleaning.



## HOLLOW CONE SPRAY PATTERN

A hollow cone spray pattern is made of droplets concentrated on a ring-shaped impact area, with no droplets falling inside the conic volume. Under the same operating conditions, hollow cone nozzles produce a very fine atomized liquid mist and can capture a higher rate of suspended particles than other nozzles. They are widely used in exhaust scrubbers and gas cooling.

### HOLLOW CONE (Turbulence nozzle)

These nozzles use a tangential injection of liquid into a whirling chamber to generate centrifugal forces which break up the liquid vein as soon as it leaves the orifice. Precisely designed orifice profiles, making use of the Coanda effect, provide the ability to obtain very large spray angles.

### HOLLOW CONE (Deflection nozzle)

A hollow cone can also be obtained taking a liquid flow to change direction onto a properly designed surface in order to break the liquid into droplets and distributes them as a hollow cone spray pattern with clog resistance. This kind of nozzle is mainly used for applications in fire-fighting systems.







## Correct overlapping

When several nozzles are used to spray, it's very important to produce a uniform spray distribution. The correct sprays overlapping methods are shown here below.



### Standard convex distribution

In a standard convex spray distribution the medium section has a larger capacity than the two lateral sections. It's necessary to overlap 50% of the spray range.



### Standard even distribution


An equal distribution provides a uniform spray and 10% of the spray range overlaps.



## Offset


Spray angle	Offset ( $\alpha$ )
15°~60°	5°~10°
60°~120°	10°~15°

A flat fan nozzle produces a high impact jet with a 5°-15° offset angle to avoid overlapping and interference. The offset angle depends on the spray range of the flat fan nozzle.




## Flat fan nozzles - low pressure, wide angle

K series nozzles work on the principle of jet deflection, conveying the liquid against an accurately machined sloping surface to change the flow direction and produce a fan-shaped mist with a 75° spray angle. Medium-sized droplets and medium/low impact values.




## Flat fan nozzles - high impact

K nozzles high-impact type work on the principle of jet deflection. The liquid flow is conveyed onto a deflection sloping surface specially designed to produce a high impact narrow flat fan and medium-sized droplets. They are widely used in operating environments requiring high impact spray jets. Moreover, their rounded orifice and free inside passage minimize the risk of clogging. There is a specific angle that must be kept to ensure spray direction (see below picture ~ CL).




## Dovetail flat fan nozzle




Flat fan nozzle tips provide a high impact spray. Adjacent nozzles must rotate with a specific offset angle to avoid interference and produce a uniform spray coverage when their jets overlap. For the GY series nozzle tips an offset angle  $\sim \alpha$  must be set between the spray plane and their dovetail guide.


Their specific dove-tail design ensures the correct spray direction and allows time saving as spray angles must not be adjusted each time. For thread size 3/8" offset angle is 5°. For thread size 3/4" offset angle is 15°. The picture to the right shows an offset angle  $\sim \alpha$  between the spray plane and the dovetail.



## Equivalent nozzle tip diameter



Flat fan nozzles produce cat-eye shaped or parabolic distribution patterns with different capacities. Hence nozzle tips have long and short side differences. For convenience reasons, their "cat-eye shaped" spray pattern is converted into the area of a circle. The datum so obtained from the conversion is called "equivalent nozzle tip diameter".















## Flanged nozzle

Flanged nozzles have no thread. The nozzle tip is installed on a welding nipple and fastened with a locknut.

The scope of their design is:

1. Easy adjustment of the spray direction
2. Easy maintenance







## HIGH PRESSURE WASHING

Flat fan nozzles F series are designed for high-pressure washing applications. Their specially designed inner profile allows for even jet distribution, which results in effective and uniform cleaning action over the surface being processed. All nozzles are precisely machined and made of hardened stainless steel AISI 416.


• **Thread specification:** BSPT, NPT

• **Typical applications**

- Car washing
- High pressure washers
- Industrial cleaning



Spray section



Even distribution




Nozzle type	Thread size
FA - FG	1/8" BSPT - 1/8" NPT
FB - FH	1/4" BSPT - 1/4" NPT
FX	Ø14.7

0°		15°		25°		40°		65°		US Gals	PNR Code	Capacity at different pressure values (l/min) (bar)										
FAA	FBA	FXA	FAB	FBB	FXB	FAD	FBD	FXD	FAL			FBL	FXL	FAR	FBR	FXR	20	30	50	70	100	150
•	•	•	•	•	•	•	•	•	•	•	015	1340	1.52	1.86	2.40	2.84	3.40	4.16	4.81			
•	•	•	•	•	•	•	•	•	•	•	02	1460	2.06	2.52	3.25	3.85	4.60	5.63	6.51			
•	•	•	•	•	•	•	•	•	•	•	025	1560	2.50	3.07	3.96	4.69	5.60	6.86	7.92			
•	•	•	•	•	•	•	•	•	•	•	03	1686	3.07	3.76	4.85	5.74	6.86	8.40	9.70			
•	•	•	•	•	•	•	•	•	•	•	035	1812	3.63	4.45	5.74	6.79	8.12	9.94	11.5			
•	•	•	•	•	•	•	•	•	•	•	04	1930	4.16	5.09	6.58	7.78	9.30	11.4	13.2			
•	•	•	•	•	•	•	•	•	•	•	045	2103	4.61	5.64	7.28	8.62	10.3	12.6	14.6			
•	•	•	•	•	•	•	•	•	•	•	05	2116	5.19	6.35	8.20	9.71	11.6	14.2	16.4			
•	•	•	•	•	•	•	•	•	•	•	055	2126	5.63	6.90	8.91	10.5	12.6	15.4	17.8			
•	•	•	•	•	•	•	•	•	•	•	06	2138	6.17	7.56	9.76	11.5	13.8	16.9	19.5			
•	•	•	•	•	•	•	•	•	•	•	065	2149	6.66	8.16	10.5	12.5	14.9	18.2	21.1			
•	•	•	•	•	•	•	•	•	•	•	07	2160	7.16	8.76	11.3	13.4	16.0	19.6	22.6			
•	•	•	•	•	•	•	•	•	•	•	075	2170	7.60	9.31	12.0	14.2	17.0	20.8	24.0			
•	•	•	•	•	•	•	•	•	•	•	08	2181	8.09	9.91	12.8	15.1	18.1	22.2	25.6			
•	•	•	•	•	•	•	•	•	•	•	085	2192	8.59	10.5	13.6	16.1	19.2	23.5	27.2			
•	•	•	•	•	•	•	•	•	•	•	09	2204	9.12	11.2	14.4	17.1	20.4	25.0	28.8			
•	•	•	•	•	•	•	•	•	•	•	095	2220	9.84	12.1	15.6	18.4	22.0	26.9	31.1			
•	•	•	•	•	•	•	•	•	•	•	10	2230	10.3	12.6	16.3	19.2	23.0	28.2	32.5			
•	•	•	•	•	•	•	•	•	•	•	11	2248	11.1	13.6	17.5	20.7	24.8	30.4	35.1			
•	•	•	•	•	•	•	•	•	•	•	12	2272	12.2	14.9	19.2	22.8	27.2	33.3	38.5			
•	•	•	•	•	•	•	•	•	•	•	12.5	2280	12.5	15.3	19.8	23.4	28.0	34.3	39.6			
•	•	•	•	•	•	•	•	•	•	•	13	2296	13.2	16.2	20.9	24.8	29.6	36.3	41.9			
•	•	•	•	•	•	•	•	•	•	•	14	2320	14.3	17.5	22.6	26.8	32.0	39.2	45.3			
•	•	•	•	•	•	•	•	•	•	•	15	2341	15.2	18.7	24.1	28.5	34.1	41.8	48.2			
•	•	•	•	•	•	•	•	•	•	•	16	2360	16.1	19.7	25.5	30.1	36.0	44.1	50.9			
•	•	•	•	•	•	•	•	•	•	•	18	2410	18.3	22.5	29.0	34.3	41.0	50.2	58.0			
•	•	•	•	•	•	•	•	•	•	•	20	2456	20.4	25.0	32.2	38.2	45.6	55.8	64.5			
•	•	•	•	•	•	•	•	•	•	•	25	2567	25.4	31.1	40.1	47.4	56.7	69.4	80.2			
•	•	•	•	•	•	•	•	•	•	•	30	2682	30.5	37.4	48.2	57.1	68.2	83.5	96.4			
•	•	•	•	•	•	•	•	•	•	•	35	2800	35.8	43.8	56.6	66.9	80.0	98.0	113			
•	•	•	•	•	•	•	•	•	•	•	40	2910	40.7	49.8	64.3	76.1	91.0	111	128			
•	•	•	•	•	•	•	•	•	•	•	50	3113	50.5	61.9	79.9	94.5	113	138	160			
•	•	•	•	•	•	•	•	•	•	•	60	3135	60.4	73.9	95.5	113	135	165	191			

HOW TO MAKE UP THE NOZZLE CODE

EX.: FAA 1340 C2




**OUTER DIMENSION OF F TYPE NOZZLES AND FX NOZZLE TIPS (CODE)**

The table on the right shows the correspondence between the nominal capacity in US Gallons per minute at 40 psi, which is commonly used to identify high pressure washing nozzles and the PNR capacity code at 100 bar. For the convenience of worldwide use, all nozzles are US coding system.


For example:

**FBA 1686 C2** (PNR code) nozzle will be codified as **00/03** (US Gallons) with a spray angle 0° and capacity 0.3 Gals/min at a pressure of 40 psi.

**FBD 2116 C2** (PNR code) nozzle will be codified as **25/05** (US Gallons) with a spray angle 25° and capacity 0.5 Gals/min at a pressure of 40 psi. (see below)



US Gals	PNR Code
015	1340
02	1460
025	1560
03	1686
035	1812
04	1930
045	2103
05	2116
055	2126
06	2138
065	2149
07	2160
075	2170
08	2181
085	2192
09	2204
095	2220
10	2230
11	2248
12	2272
12.5	2280
13	2296
14	2320
15	2341
16	2360
18	2410
20	2456
25	2567
30	2682
35	2800
40	2910
50	3113
60	3135



**HIGH PRESSURE WASHING ACCESSORIES**

We have all kinds of washing guns (low/medium/high/superhigh pressure) and accessories for various washing applications and environments. We will help you to chose the best solution for your needs.



**UMW 0010 D4**  
High pressure gun  
( P.95 )



**UMW 0020 D4**  
High pressure gun  
( P.95 )



**UMW 0030 B3**  
High pressure lance  
( P.96 )



**UMW 0045 B3**  
High pressure lance  
( P.96 )



**UMU J / I**  
Auto-rewind reels  
( P.100 )

**OPTIONAL ELEMENT- FLOW STRAIGHTENER**

Flow straighteners improve spray jet efficiency by straightening the liquid path to minimize turbulence and produce swirl-free, even, stable and straight-run flows. All PNR nozzles are ready to embed a flow straightener.



These items can be supplied separately on request.




**AIR & STEAM FLAT FAN TIPS**

GZ air & steam flat fan tips are ideal for gas application. They are widely used in drying processes.

- **Typical applications:** water removal from surfaces, flocks and water blow off
- **Connection:** flanged nozzle tip




Spray section



Distribution


Code	D mm	Air capacity (Nm <sup>3</sup> /hour) at different pressure values (bar)				Steam capacity (kg/hour) at different pressure values (bar)				Spray coverage		
		0.5 bar	2.0 bar	5.0 bar	10 bar	0.5 bar	2.0 bar	5.0 bar	10 bar	2.0 bar	5.0 bar	
70°	GZS 1300 xx	1.3	1.2	3.0	6.0	11.0	0.9	1.9	3.7	6.7	70	85
	GZS 1350 xx	1.5	2.0	3.5	7.1	12.6	1.0	2.1	4.1	7.7	72	87
	GZS 1500 xx	1.8	2.3	5.3	10.7	19.5	1.7	3.3	6.6	11.8	110	125
	GZS 1800 xx	2.1	3.2	8.0	16.0	29.0	2.5	5.0	9.9	18.0	115	140
	GZS 2150 xx	2.8	5.4	13.0	26.0	48.0	4.2	8.2	16.0	29.0	130	170
	GZS 2200 xx	3.6	8.9	21.7	43.3	79.4	6.8	13.6	27.0	48.0	140	180
GZS 2315 xx	4.3	13.0	31.8	65.6	120.2	10.3	20.6	40.4	73.0	170	215	

**ASSEMBLY FITTINGS**



**HOW TO MAKE UP THE NOZZLE CODE**

EX.: GZS 1300 B1



- MATERIAL**
- B1 - AISI 303 Stainless steel
  - B31 - AISI 316L Stainless steel
  - T1 - Brass